



P.O. BOX 61
9819 S. 51ST AVE
LAVEEN, AZ 85339
PHONE (602) 237-4506
FAX (602) 237-9633
www.gottashow.com

ATTENTION!!!

PLEASE READ BEFORE ASSEMBLY

HEATER INSTRUCTIONS AND CRIMP SPECIFICATIONS

1. Fittings will work with any standard **#10 A/C** barrier hose (not reduced barrier).
2. Hoses can be crimped with any standard a/c crimper and **#10 A/C DIES** for standard barrier hose (not reduced barrier hose) this also includes most hand held crimp tools for standard barrier a/c hose.

Note: Install crimp collars onto the end of the hose before inserting the fitting. You may use refrigerant oil on the barb of the fittings to help the fittings slide down into the hose.

Kit includes:

- (2) #10 female o-ring long drop fittings
- (2) large crimp collars
- (2) AN fittings for engine side adapters
- (1) 90 degree intake adapter
- (1) Straight water pump adapter
- (2) Bulkhead o-rings